


# **Technical Parts Gram #62:**

## **Connecting Rod Bearings for ISX Fracture-Split Rod Applications**

Part number 2882087 fracture-split connecting rod bearings have a small tab at the corner, which may serve only for identification purposes. However, aftermarket manufacturers like Interstate-McBee may produce bearings without this tab. Extra caution should be taken during installation to ensure the correct orientation and fitment of the bearings. Installing rod bearings incorrectly can lead to oil starvation, excessive wear, and potential engine failure. Extra care ensures proper function and longevity.



### Tips to Avoid Installation Mistakes:

- Verify Orientation: Even without the tab, ensure the bearing shells align properly with rod and cap.
- Check Part Numbers: Confirm the bearings match the engine specifications before installation.
- Inspect for Oil Holes & Notches: Some bearings may have specific features for oiling that must align properly.
- Follow Torque Specs: Always use the recommended torque values and procedures to prevent premature failure.
- Lubricate Properly: Use correct assembly lube/ engine oil to avoid dry starts.

### SERVING THE DIESEL AND NATURAL GAS INDUSTRY FOR OVER 75 YEARS

FLORIDA 9955 NW 58th St. Doral, FL 33178 PH: 305-863-6650 Fax: 305-863-6272 **CALIFORNIA** 13137 Arctic Circle Santa Fe Springs, CA 90670 PH: 562-356-5414 Fax: 562-926-2452

#### WORLD HEADQUARTERS 7440 Oak Leaf Rd. Oakwood Village, OH 44146 PH: 216-881-0015

Fax: 216-881-0805

TEXAS 22755 NW Lake Dr., Bidg #3 Houston, TX 77095 PH: 281-645-7168 Fax: 281-443-0202 NEBRASKA 6200 Arbor Rd. Lincoln, NE 68517 PH: 402-417-1059 Fax: 402-975-6160

